

In addition to the RECORD button, specially programmed PT+z Controller™ units are programmed with a complex joystick move to start and stop recording as well as a camera standby button.

The units programmed with this custom firmware can be identified by a record button that protrudes out and a camera **standby button** located on the rear panel of the PT+z Controller™ above the 3.5mm jack. Pressing the **standby button** for more than 2.5 seconds turns off the camera allowing prolonged battery life when the camera is not being used. To wake up the camera simply hit the RESET button located on the rear panel of the PT+z Controller™.

The joystick move that allows the recording to start or stop is engaged by **pressing in both zoom buttons and pushing the joystick up at the same time**. This becomes useful when stopping and starting the unit repeatedly or when the unit is not within easy reach.

